


LEFT GRIP

D2 LED:
Camera: None

S5: Exp. Focus
Shift S5: Shutter On/Off

S2: Moment. AF
Shift S2: AF Toggle On/Off

S3: Shift Key



D1 LED:
Camera: None
Alarm : Blinking Red

S4: Gain Select
Shift S4: Gain On/Off

S1: Moment. Auto Iris
Shift S1: Iris A/M Toggle

RIGHT GRIP

D2 LED:
Camera : Solid Green
Rec. : Blinking Green
No Media: Solid Amber

S5: Fast Zoom W
Shift S5: WB "A"
Nav S5: Down


S2: Display Toggle
Shift S2: WB Preset
Nav S2: Left

D1 LED:
Camera Navigation : Solid Green
Alarm : Blinking Red

S4: Fast Zoom T
Shift S4: WB "B"
Nav S5: Up

S1: One Push WB
Shift S1: Auto/Manual
WBToggle
Nav S1: Right

S3: Record Start/Stop
Shift S3: Toggle Nav. Mode
Nav S3: Execute




Right Wheel: Zoom W & T Vaiable Range
Shift Right Wheel: Manual Iris

MENU CONTROL PANEL

S1: Menu Toggle
Shift S1: Assign 4

S3: Assign 1
Shift S3: Assign 6
** Hold For Test Mode Exit **



S2: Picture Profile Toggle
Shift S2: Assign 5

S4: Assign 2
Shift S4: Power Off
** Test Mode At Power-Up **

Left Wheel: Focus N & F
Shift Left Wheel: Shutter
Select Up/Down

